



Counter Top Protective Screen / SG3-XXXX Freestanding Unit

Installation Instructions


Step 1: Remove and unpack the Thermoplastic Panel, and Hardware.




Step 2: Screw each Leg Assembly onto the Base. Use one (1) Screw per Leg. Make sure standoffs face towards each other, and Legs are parallel to one another.



Step 3: Lay the Thermoplastic Panel onto a clean flat surface. Remove the film outer layer. Slide the panel through the standoffs.



Step 4: Move the Thermoplastic Panel to optimal height and tighten standoffs with the Allen Wrench.



Step 5: Recycle all packaging in accordance to local regulations.