




SG2 ASSEMBLY INSTRUCTIONS



COMPONENTS		
ACRYLIC	1	
FOOT	2	

REQUIRED TOOLS – PHILLIPS SCREWDRIVER

1. REMOVE BLUE PROTECTIVE COVERING FROM ACRYLIC.
2. INSERT ACRYLIC INTO THE FOOT SLOTS.
3. USE PHILLIPS SCREWDRIVER TO SNUG THE SCREWS TO GRIP THE ACRYLIC.