

WADDELL

CARE & CLEANING INSTRUCTIONS

.....

GENERAL CARE & CLEANING

GLASS DISPLAY CASES AND SHELVES AND LAMINATE SURFACES



We do not recommend using harsh cleaners on your Waddell product. For general cleaning, simply wipe the surfaces clean with a soft, wet cloth.

For glass doors and shelves, use a glass or window cleaner that will not leave marks and streaks on the surface.

For Formica® Laminates, we recommend disinfecting with:

- 1) Quaternary Ammonium which is the largest group (198 listed) of EPA approved disinfectants. Examples of include: Clorox® Disinfecting Wipes, Lysol®, Virex®, etc.
- 2) Alcohols both Ethanol and Isopropanol. Examples include: Purell® Professional Surface Disinfectant Wipes, Klercide™ 70/30 IPA
- 3) Sodium Hypochlorite or Bleach. Examples include: Clorox Healthcare® Bleach Germicidal Wipes, Ultra Clorox® Regular Bleach 8.25%, Caviwipes™ Bleach...
- 4) Hydrogen Peroxides. Examples include: Clorox Commercial Solutions® Hydrogen Peroxide Cleaner Disinfectant, Oxivir®, Accel®

Always follow cleaning or disinfectant with a warm water rinse and dry.

DISINFECTING YOUR PLASTIC SHIELD



When disinfecting or sanitizing plastic or acrylic surfaces, proper procedures should be taken. To minimize the risk of damage, use only compatible household cleaners listed below.

- Pharmacy grade hydrogen peroxide
- Isopropyl alcohol - dilute with water to 30% strength
- Household grade bleach - dilute with 50 parts water to 1 part bleach

Polycarbonate and plastic products were tested on uncoated sheets. Do not use unapproved cleaners or disinfectants on sheet products. Generally speaking soap and water, hydrogen peroxide and isopropyl alcohol-based sanitizers work best as disinfectants on polycarbonate. Disinfectants containing hydroxides, dimethyl benzyl or ethyl ammonium chloride, ethylenediamines and hypochlorite will crack the polycarbonate sheets.

